



Empowering Racers Since 1989

GV Home Page



K&N BIRDCATCHER RACING FILTER (p/n FI-7002.KN) Installation Instructions

REQUIRED TOOLS & SUPPLIES:

- Electric Drill
- 1/4in Drill Bit
- Marker or Center Punch
- Tape Measure

STEP 1 — INSTALL MOUNTING HOLE LOCATIONS:

1. Measure & mark the mounting hole locations on the injection hat. Drill 2 mounting holes using the following dimensions & ensure both holes are aligned evenly on opposite sides:
 - 1.50in **up** from the Throttle Stop
 - .500in **inward** from the Edge of the Hat

STEP 2 — FIT THE FILTER:

1. Hold the K&N filter tightly against the Injector, slightly compressing the gasket to create a proper sealing surface
2. Drill through the Injector & through the Filter Flange

STEP 3 — INSTALL QUICK RELEASE PINS:

1. Insert the two 1/4in spring-loaded quick release pins through the injection hat and filter flange
2. Confirm that the filter fits tightly, the gasket seals evenly & the filter is securely attached

