


Display Panel



How to use:

1. Connect the AC cord to the socket, The "power" lamp will light on solid.
2. Connect positive charger clip (red) to positive battery terminal, the black clip to negative. (You can use other dc plugs to connect battery), the "25%~100%" lamps will light on flowing. If the battery polarity reversed or output shorted, all lamps will flashing, please check the setup.
3. Depend on the charged capacity, 25%~100% lamps will lights up solid sequence, until the battery is fully charged. Then you can power off the charger and disconnect the battery or you can charge a new battery if you need.

The table shows the duration of 80% state charged for an empty battery.

Battery type (Ah)	G100-12A	G100-24A	G100-36A
12	Not recommend	5 hours	7 hours
22	5 hours	9 hours	12 hours
40	9 hours	14 hours	20 hours
80	16 hours	Not recommend	Not recommend